



Restorative (Stage 2) Full Arch Restoration

STEPS

- Record bite of existing immediate load temporary appliance while in the mouth.
- Remove appliance and duplicate (lang duplicator) or scan with interoral scanner IOS by scanning the intaglio and occlusal – 3Dimensionalizing the whole appliance
- If 2 arches – bite first, scan upper and lower as described above
- If 1 arch – bite first, scan the appliance outside the mouth as described above and take an opposing impression or opposing scan
- Take final open tray impression over the multi-unit abutments that are in the mouth
- Mark the Rx with the shade, any aesthetics changes needed from the existing immediate temp and any changes to the vertical of the immediate temp
- Send .STL file and impressions to us.

You can upload the .STL file to our DDX site and any pictures and any analog impressions can be mailed or delivered to us.

After the above STEPS, you will receive a Verification Jig and Aesthetic Screw Retained Try-in in approximately 10 Days